


YELLOW JACKET

Operators and Maintenance Manual



DISC MOWER

GB**General information**

- 1.1. Introduction.....pag. ...27
- 1.2. Use.....pag. ...27
- 1.3. Warranty.....pag. ...27
- 1.4. Machine identification data.....pag. ...28

Technical specifications

- 2.1. Characteristic datapag. ...29
- 2.2. Tractor requiment.....pag. ...29
- 2.3. Packaging for shipment.....pag. ...29

Safety regulations

- 3.1. General recommendation
for the prevention of dangerpag. ...30
- 3.2. Road circulation.....pag. ...32
- 3.3. Stickers.....pag. ...32
- 3.4. Transport.....pag. ...33
- 3.5. Safety trippag. ...33

Assembly

- 4.1. Assembly instructionpag. ...34
- 4.2. List of parts.....pag. ...38

Installation instructions

- 5.1. Adapting to the tractor.....pag. ...39
- 5.2. Adapting the universal
coupling.....pag. ...39
- 5.3. Road circulation.....pag. ...40

Adjustments and registrations

- 6.1. Belt tensioning.....pag. ...41
- 6.2. Cut heightpag. ...41

Use Instructions

- 7.1. Working position.....pag. ...42
- 7.2. Mowing.....pag. ...42

Fault and remedy

- 8.1. Troubleshooting.....pag. ...43

Maintenance

- 9.1. Cutter fastening.....pag. ...45
- 9.2. Checking and replacing
the cutting parts.....pag. ...45
- 9.3. General maintenancepag. ...46
- 9.4. Lubrication.....pag. ...47
- 9.5. Off-season storage.....pag. ...48

F**Caracteristiques generales**

- 1.1. Introductionpag. ...49
- 1.2. Utilisation prevue.....pag. ...49
- 1.3. Garantiepag. ...49
- 1.4. Donnees d'identification
de la machine.....pag. ...50

Caracteristiques techniques

- 2.1. Données techniquespag. ...51
- 2.2. Caracteristiques requises
au tractor.....pag. ...51
- 2.3. Enballage pour l'expedition.....pag. ...51

Consignes de securite

- 3.1. Recommandations generales
de securite.....pag. ...52
- 3.2. Circulation sur route.....pag. ...54
- 3.3. Etiquettes adhesives.....pag. ...54
- 3.4. Transport sur route.....pag. ...55
- 3.5. Debrayage de securite.....pag. ...55

Assemblage

- 4.1. Instructions de montage.....pag. ...56
- 4.2. Liste des composantspag. ...60

Instruction d'installation

- 5.1. Adapting au tractor.....pag. ...61

- 5.2. Adaptation de l'arbre
a cardanspag. ...61
- 5.3. Deplacement sur.....pag. ...62

Reglages et ajustages

- 6.1. Tension des courroies.....pag. ...63
- 6.2. Hauteur de coupe.....pag. ...63

Mode d'emploi

- 7.1. Position de travail.....pag. ...64
- 7.2. Fauchagepag. ...64

Inconvenient et remedes

- 8.1. Inconvenients:
causes et remedes.....pag. ...65

Entretien

- 9.1. Fixation des dispositifs
de coupepag. ...67
- 9.2. Controle et remplacement des
dispositifs de fauchage.....pag. ...67
- 9.3. Entretien general.....pag. ...68
- 9.4. Graissage.....pag. ...69
- 9.5. Entreposage a la fin
de la saison.....pag. ...70

1.1. Introduction

Thank you for choosing a FORT mower. This machine has been specially designed for agricultural use and therefore.

Read the instructions in this operating manual carefully and follow them exactly when using the machine since its long working life and safe operation depend on putting into practice all the information and helpful hints provided here.

You will also avoid accidents and insure that the manufacturer's Warranty holds good for the entire period and, last but not least, your machine will be always ready to do a fine job whenever you call on it.

The FORT rotary cutter mower has been designed as a simple, easily maintained machine. Thus if there are problems with its mowing performance, the most likely cause is to be found in worn working parts.

Change these as needed but use ONLY genuine original parts which are available from your local FORT dealer.

We recommend that you follow all the regulations for preventing industrial accidents and all current laws of the road governing agricultural machines. Messrs.

FORT declines any responsibility for injury or damages caused by failure to observe the laws and the regulations above mentioned.

IMPORTANT: at FORT the continuous improvement of our products is an on-going process and therefore we retain the right to make whatever changes we deem necessary to our machines at any time without prior notice and without being obliged to up-date machines already sold.

1.2. Use

Fort mowers are designed for specific farming use in order to cut normally cultivated forage crops.

All other use shall be considered improper, not recommended and therefore at the user's risk.

1.3. Warranty

Messrs. FORT, Luzzara (Reggio Emilia, Italy) hereby guarantee every new machine from its plant against all fabrication defects provided that the operating and maintenance regulations given in the user manual are carried out. Failure to do so shall invalidate the warranty.

The machine is covered by warranty for 6 (six) months from its commissioning but, in any case, not more than one year from the date it was delivered:

Damage caused by the following are not covered by warranty: normal wear and tear, accidents caused by negligent or improper use of the machine, inadequate or improper maintenance, abnormal use of the machine.

The warranty shall be equally null and void where changes have been made to the machine without prior written permission from the manufacturer or when repair are made using non-original parts or where the work is carried out by non-authorized dealers.

The warranty is limited to the replacement of or refund for such parts as are found defective by Fort Technical Department.

Messrs. Fort shall not be responsible, apart from the limits stated above, for any reimbursement or compensatory payment on any basis whatsoever.

Warranty claims shall be sent solely through the dealer or authorized dealership which sold the product or, if the sale was made directly by Messrs. FORT, the claim should be sent to our headquarters.

Apart from in-house sales, all machines delivered should be checked on arrival to make sure that there has been no damage during transport. **All claims for such damage should be made within and no later than 6 days from the date of delivery.**

1.4. Machine identification data

- Model: F25
- Incremental number
- Year of manufacture

stamped on the plate attached to the machine's chassis. Always specify this information when ordering parts or requesting information.

Use only original spare parts available at your local FORT dealer.

2.1. Characteristic data

	F25/4	F25/5	F25/6	F25/7
Working widthm	1.65	2.05	2.40	2.80
Number of disksn°	4	5	6	7
Number of tines per diskn°	2	2	2	2
Disk rotation speed for Pto = 540rpm	3075	3075	3075	3075
Minimum power ratingkW/HP	26/35	30/40	34/46	38/52
Total weight (*)Kg	335	370	405	455
(*) excluding cardan shaft				

2.2. Tractor requirements

Ptorpm	540
Minimum power ratingkW (HP)	from 26(35) to 38(52) according to model
Maximum pressure hydraulic systembar	160
Single-acting spool valven°	1

2.3. Packaging for shipment

The mowers are dispatched with the disk bars separate from the tool bar structure and packed one by one. The weights and dimensions of the rectangular shaped packages are listed below:

Package	(*) Weight(Kg)	Length(m)	Width(m)	Height(m)
1 mower with 4 disks	390	1880	720	720
1 mower with 5 disks	425	2310	720	720
1 mower with 6 disks	460	2660	720	720
1 mower with 7 disks	520	3160	720	720

(*): overall weight of the pack including the cardan shaft.



The crates should be handled by fork lift truck in compliance with common safety regulations.

3.1. General recommendations for the prevention of danger

Most of the accidents that occur during work, transport and maintenance are caused by failure to comply with the elementary rules of caution.

During work, always strictly comply with the safety regulations in force in the individual countries of use.

The following is a list of precautions the operator should take when using the machine. In certain illustrations, the machine may be depicted with the guards removed for explanatory purposes.

Always check that all protections are activated before operating the mower.

Become thoroughly familiar with the Use and Maintenance Instructions before proceeding with any operation on the machine (starting, use, adjustment, servicing, etc.): see Fig. 01.




WARNING: this signal indicates a hazard and will be used each time either persons and/or the machine could be harmed!

 The operator **should have become fully familiar with correct use** of the machine before working with it alone (Fig. 02).

 Before beginning work, always check that all safety devices **are efficient** and that the guards are mounted. Remember that the protective cover becomes worn and will eventually need replacing.

 The cutters, relative fixing screws and disks must be immediately **replaced** if they appear faulty or worn beyond the permitted extent. The lower skids are also liable to wear.



⚠ Check that your mower is always in a good condition and that **only genuine FORT spares** are used for repairs.

⚠ Periodically check that the **nuts are well tightened**, especially those that fix the cutters and cutter disks.

⚠ **Never open** the casings or guards whilst the machine is moving (Fig.03).

⚠ **Never exceed** the prescribed pto rpm rate: 540 rpm (Fig. 04).

⚠ **Fix the cardan shaft shield** with the relative latch in order to prevent the shaft itself from turning (Fig. 05).

⚠ Before lowering the machine from the **transport position** to that of **work** or vice versa, always check that there are no persons, animals or other obstructions in the range of action of the machine itself (Fig. 06).

⚠ Couple the mower with the guards strictly lowered and with the **bar reasting on the ground** in the work position.

⚠ **Further any person** away from the immediate vicinity of the mower or from the area where soil may be thrown up at the rear in order to avoid injuries from flying stones or other foreign bodies (Fig. 07).


⚠ Pay particular attention when working **near roads, paths or on stony ground**. In this case, it is advisable to **increase the mowing height**.

⚠ **Never approach the mower whilst it is working**. Accidental contact with the turning cutters could cause serious injuries (Fig. 08).
Never leave the machine **unattended** when the pto is engaged.

⚠ Before carrying out any operation on the mower, always remember to disengage the pto, turn off the tractor engine and check that the tractor is braked.

Remove the keys from the instrument panel.

Wait until all moving components have stopped (Fig. 09).



- ⚠ Never work on the hydraulic system **without having first relieved the pressure**.
- ⚠ Besides complying with the above recommendations, always conform to the safety provisions **in force** in the various countries of use.

3.2. Road circulation

- ⚠ Always comply with the Highway Code **in force** in the country of use during road circulation.
- ⚠ **Never carry passengers** on the machine or tractor either during work or during road circulation (Fig. 10).
- ⚠ **It is forbidden** to use the mower as a **means of transport**.
- ⚠ Set the machine to the **transport position** before any journey, even over a short distance. Also check that the mower is stable and that all **safety stops** have been engaged.
- ⚠ Never allow **unauthorized** persons to sit in the driving seat.

FORT declines all responsibility for any damage to persons or property caused by failure to comply with the safety provisions.

3.3. Stickers

- ⚠ It is essential to pay the **greatest attention** to the safety stickers affixed to the machine.
- ⚠ The user shall be obliged to keep all safety stickers in a good condition. They must be **perfectly legible**.
Contact the Spares Service if the safety stickers need replacing.



The indication "IMPORTANT" on the machine reminds the user about instructions or recommendations which, if ignored, could cause bad operation or damage to the machine itself.

3.4. Transport

The packaged mower should be loaded and unloaded by means of fork lift trucks.

 **The user must employ lifting equipment which is suited to the weight of the machine in question.**

 **No person** must stand within the range of action of the lift truck during the **loading** and **unloading** operations.

 **Never move** the hanging load sharply whilst it is being handled.

3.5. Safety trip


When the cutter disk arm encounters an obstruction during mowing, the safety trip operates and **the machine can be reversed without damage** to the bar. To reset the mower for cutting, reverse until the safety released is engaged.

Keep an eye on this device to make sure it is always efficient. Grease it frequently.

The spring **should be adjusted** to the following lengths (see Fig. 11):


4 and 5-disk bar $L = 87 \text{ mm}$

6 and 7-disk bar $L = 85 \text{ mm}$




4.1. Assembly instructions

- 1 - Fix skid 33 under the overdrive-housing of bar 4, using the two front bolts 42, 43, the two rear bolts 42, 44 plus the relative Grower washers 41 and self-locking nuts 14.
Use bolts 42 (internal) and 44 to fix plates 49 and 50 respectively.
If they have not already been installed, mount the cutters (right and left types) so that the arrow stamped on the cutter itself complies with the turning direction of the disk.
Fix the cutters with the pins, cup washers (concavity pointing downwards) and nuts.
The correct driving torque is **7.5 Kgm (7.5 daNm)**.
- 2 - Fix support foot 2 in its relative housing in toolbar unit 1 by means of latch 13 and pin 12.
Fix the disengaging device on the inner plug of the toolbar arc, placing spacer 17 and lift locking chain 10 in between. Lock in place with spring pin 31.
- 3 - Connect toolbar unit 1 and bar unit 4, fitting articulation bush 25 in between and locking in place with the two bolts 27, the Grower washers 26 and the flat washers 59.
- 4 - Connect the central shield assembly 32 to the overdrive housing of bar 4, using bolts 46 and Grower washers 41.
- 5 - Connect the bottom of the lift control rod to the central shield coupling plate, using pin 21 and split pin 22.
Connect the top of the lift control rod to the end of the hydraulic cylinder stem by means of pin 21 and split pin 22.
NOTE: the pin head must point towards the pulley side.
- 6 - Connect hydraulic pipe 3 to the cylinder, placing copper washer 16 in between and fully tightening.
- 7 - Fix upper internal guard 7 and lower internal guard 8 beside toolbar unit 1 using the six stud bolts 29, the relative six washers 28 and a nut 30.
- 8 - Connect cover 6 to drive input unit 5, fixing it with the two bolts 23 and the two washers 24. Mount the drive input unit to the cross member of the toolbar, fixing it in place with anchoring bracket 20, adjuster rod 19 and the three nuts 18. Do not fully tighten. Position V-belts 15 on the pulleys and stretch them by means of the nut on idler 19 (**until achieving a deflection of about 2 cm halfway along the pulley center distance**).
Now check that the pulleys are correctly aligned and fully tighten the nuts of the anchoring bracket.
- 9 - Finish mounting external guard 9, fixing it in place with the six nuts 30 and six washers 28.



- 10- Fix internal conveyor 34 to the relative three connection points using the three bolts 51, the nuts 48 and the washers 28.
Fix windrow forming rod 36 to the external plate 35 using bolts 55, 56, the two washers 24 and the two nuts 57.
Initial adjustment can take place by setting bolt 55 in the intermediate hole of the three available positions.
Connect the external plate to the plate support by means of bolt 52. Now insert spring 53, washers 54 and 28 and nut 30 in that order.
- 11- Connect upper guard 37 to central pipe 32, fixing it with a bolt 58 and a nut 30 for each coupling element.
Now connect rear guard 38, fixing it with two bolts 58 and two nuts 30 for each coupling element with the exception of the outermost one.
- 12- Along with the guard, also fix cover guiding bracket 61 to the outermost element coupling, using two bolts 60 and two nuts 30 (only for bars with 4,5,6 disks).
- 13- On 7-disk bars, connect the end of guard assembly 32 to the end of the bar unit using lower bolt 47, bolt 42 with its relative washer 63 and self-locking nut 14.
Now fix conveyor plate 62 using the four bolts 51, the washers 28 and the nuts 48.
- 14- Keeping the front guard lowered, correctly position protective cover 39, fixing it in place with clamps 40.

Check that all nuts and bolts have been correctly torqued.



4.2. List of parts

Position	Description	N° pcs (4/5/6/7 disks)	Position	Description	N° pcs (4/5/6/7 disks)
1	Toolbar unit	1	33	Overdrive skid	1
2	Support foot	1	34	Internal conveyor	1
3	Hydraulic pipe in rubber	1	35	External plate assembly	1
4	Disk bar unit	1	36	Windrow shaping rod	1
5	Drive input unit	1	37	Front guard	1
6	Cardan shaft cover	1	38	Rear guard	1
7	Upper inner shield	1	39	Protective cover	1
8	Lower inner guard	1	40	Cover fixing clamp	2/2/3/4
9	Rear belt guard	1	41	A 12 Grower washer	8
10	Lift locking chain	1	42	M12x40 hex bolt	2/2/2/3
11	Ø6 spring pin - Type R	1	43	M12x35 hex bolt	1
12	Ø3 spring pin - Type R	1	44	M12x45 hex bolt	1
13	Foot adjusting latch	1	45	Lift control rod	1
14	M12 self-locking short hex nut	4/4/4/5	46	M12x30 hex bolt	4
15	Ø4 spring pin - Type R	1	47	M14x50 hex bolt	-/-/-1
16	V-belts	4	48	M10 tall hex nut	3/3/3/7
17	Ø28 inner spacer	1	49	Conveyor coupling plate	1
18	M14 self-locking short hex nut	3	50	Conveyor coupling fin	1
19	Drive transmission adjuster rod	1	51	QST M10x20 cap screw	3/3/3/7
20	Drive transmission fixing	1	52	M10x80 hex bolt	1
21	Bar lifting connecting rod pin	2	53	Plate return spring	1
22	Ø4x35 split pin	2	54	Ø11x40x3 washer	1
23	M8x16 hex bolt	2	55	QST M8x35 cap screw	1
24	Ø8.4x17x1.6 washer	4	56	QST M8x25 cap screw	1
25	Bar articulation bush	1	57	M8 self-locking short hex nut	2
26	A 16 Grower washer	2	58	M10x60 hex bolt	4/7/7/12
27	M16x60 hex bolt	2	59	Ø17x45x4 washer	2
28	Ø10.5x21.2 washer	16/16/16/20	60	M10x70 hex bolt	2/2/2/-
29	Casing fixing stud	6	61	Guiding bracket for protective cover	1/1/1/-
30	M10 self-locking short hex nut	14/17/17/20	62	External conveyor plate	-/-/-1
31	Ø10 pin with snap spring	1	63	Ø13x24x2.5 washer	-/-/-1
32	Shield assembly	1			



5.1. Adapting to the tractor

- 1 - Couple the machine to the tractor with the 3-point hitch. The mower can be used with tractors with different track widths by positioning the two lift arms as shown in Fig. 14 so that the distance L is about **10 cm** (the machine should be in working set up).
The lift pins can be used with 1st and 2nd category hitches (22 mm and 28 mm). In the first case, remove the adapters on the pins.
The 3-point linkage should be adjusted to that fork axis F is more or less vertical (See Fig. 15).
- 2 - Run the hydraulic lift by raising the tiller a little.
- 3 - Stabilize the tractor's two side lifting arms.
- 4 - If necessary use the vertical adjusting tierod on the lifting arm to make sure that the two ball joints are at the same height.
- 5 - Pull back the support foot P and position it in the "high" position (Fig. 15).
- 6 - Temporarily connect the lift adjusting chain hook G close to the tractor 3-point linkage, see Fig. 20.

5.2. Adapting the universal coupling

Make sure the coupling is the right length for the distance between the machine and the PTO. When commissioning the mower, follow this steps:

- 1 - Remove the two half-shafts from the coupling and connect them to the two PTOs (free-floating position).
- 2 - Bring the two halves of the coupling together.





- 3 - Check to make sure that:
- * when the coupling is in the minimum stretch position (machine lowered raised) the pipes do not touch the bottom but have a min. 20 mm play.
 - If this is not the case, reduce pipe length and the two guards. Deburr the cut ends grease (Fig. 16).
 - * When the coupling is its the maximum stretch position (safety disengaged) the pipes must overlap at least 10 cm.
- 4 - Attach the external coupling guard with its chain.

5.3. Road circulation

Always follow the Rules of the Road in force in your country.

The machine should be connected and adapted to the tractor, then carry out these operations (Fig. 17):

- 1 - Lift the mower from the ground using the tractor's hydraulic lift.
- 2 - Lock the crosspiece tierod by inserting **bolt K**.
- 3 - Fold back the front canvas skirt.
- 4 - Move the cutter disk carrier bar vertical with hydraulic cylinder **C**.
- 5 - Remove the chain from the tractor and insert the chain and pin **S** into the disk carrier bar and lock it with split pin **R**.
- 6 - Make sure the support foot is in the **high** position.



6.1. Belt tensioning




Check belt tension **routinely** but especially during the first few work hours. Follow these steps (Fig. 18):

- 1 - Loosen the two nuts D on the fixing bracket.
- 2 - Tension the belts by turning nut T on the tierod until the arrow at belt midpoint is about 2 cm and no more.
- 3 - Tighten home the two nuts D and check to make sure that the support block R is up against the crosspiece and the pulleys are nicely **aligned**.

CAUTION! The belts will wear in time and when one has to be changed, change all of them. Slacken the belts during the off season.

6.2. Cut height

Cut height can be adjusted with the **3-point hitch links** (See Fig. 19).



7.1. Working position

To go for **transporting position** to **working position** (Fig. 20) follow these steps:

- 1 - Remove the safety **chain pin S** from disk carrier bar.
- 2 - Release the hydraulic cylinder and **lower** the disk carrier arm until it is **parallel** to the ground.

 **DANGER!** Check to make sure nobody is in the working reach of the bar.

- 3 - Disengage the **latch bolt K**.
- 4 - Lower the mower using the tractor lift. Attach the lift adjustment chain to the 3-point linkage using hook G positioned as required on the chain. When the chain is stretched **pin P should about halfway along the slot** as show in the Figure.
- 5 - Lock the hook G with its spilt pin.
- 6 - Check if the coupling is **engaged** and the guard **fastened** with its chain.

7.2. Mowing

Before mowing into the crop to be cut, **lay the cutting bar on the ground**, engage the PTO and accelerate gradually.

The operating revs for the PTO should be around 540 rpm.

Ahead of time and with the **machine turned off**, check to make sure the cutters are well sharpened especially if the grass is thin, dry or sparse.

If you find that you have to work with the cutter bar at an angle for long periods of time, we recommend holding it **horizontal** for a few minutes every half hour or so of work.

 **DANGER!** As a safety measure, **make sure that there is nobody near the machine and aspecially nobody is range of the rear throw area**.
Check to make sure the guard skirts are lowered.

8.1. Troubleshooting

- * = CAUSE OF THE FAULT
- = SUGGESTED REMEDY

1 - The mower vibrates to an excessive extent during work:

- * The nylon articulation bushes are excessively worn or missing → replace / install the bushes;
- * The articulation pin of the cross member and/or the relative bushings are excessively worn → replace the worn parts and regularly lubricate;
- * The external conveyor is excessively loose → check that it is correctly fixed.

2 - The mowing bar (disk holder) fails to correctly adapt to irregular ground:

- * The height of the tractor coupling frame has been badly regulated → check the adjustment as indicated in the "Adaption to the tractor" chapter (particularly: the two lower links of the three-point hitch must be equidistant from the ground);
- * The mower articulations fail to freely turn → perfectly clean and grease all articulations.

3 - The mowing bar fails to lift parallel to the ground (even after the frame has been adjusted):

- * The perforated bar return rod is incorrectly regulated → correct regulate, by lengthening or shortening the rod.

4 - Soil accumulates between the two adjacent skids in the front part of the bar:

- * The soil is excessively wet.
- * The bar weighs on the ground to an excessive extent → adjust the tractor coupling frame to a higher position in relation to ground level, shortening the lift adjuster chain at the same time.
- * The disk bar is excessively tilted → adjust the bar tilt by means of the idler of the 3rd point of the tractor (consult the "Cutting height" chapter).

5 - The impact protecting device frequently releases:

- * Insufficient pressure from the Belleville washers → increase spring compression by degrees.

6 - The stubble is too high or too short:



- * Incorrect disk bar tilt → adjust the bar tilt by means of the idler of the 3rd point of the tractor.

7 - Stubble height uneven along the cutting width:

- * The mowing bar is excessively tilted → reduce the bar tilt;
- * The cutters are excessively worn → replace the cutters;
- * Insufficient pto speed → increase the pto rotation speed to 540 rpm but not more;
- * Excessively high advancement speed → lower the speed of the tractor.

8 - The forage is moved forwards before being cut:

- * Excessively cutter (and disk) ventilating effect → lower the pto rotation speed and increase the advancement speed of the tractor.



9.1. Cutter Fastening

From time to time (after 15-20 work hours) check the cutters and the fastenings. Check them more often if you mow on stony ground and whenever the machine bumps heavily against some obstruction.

The oval disk are mounted on a grooved shaft and should be set so that the larger axis of each is perpendicular to the adjacent disk (See Fig. 21).

The Belleville washer R should be installed with the concave part turned downwards (See Fig. 22). The lock nut should be tightened with a torque **wrench set at 18 kgm (180 Nm)**.

The cutters are attached with a special locking screws and held with a split ring and an M10 nut. The concave section of the washer should be turned down and the nut tightened with a **torque of 7.5 kgm (75 Nm)** see Fig. 22.

Pay attention to **disk direction** !

Worn cutters can be replaced or installed on the same disk to be used as the second cutter (if the wear is not excessive).

Bear in mind, however, that mowing with worn cutters will give a poorer cut and will need more power.

9.2. Checking and replacing the cutting parts




Caution!

Cutter should be replaced when:





- 1 - **they are worn:** if cutter distance from the disk is 10 mm and $\frac{3}{4}$ of the original width (Fig. 23).
- 2 - **the hole is oval shaped:** if the ovalization is 2 mm more than diameter of the original hole (Fig. 24).

The **attaching screws** are to be replaced when:

- 3 - the cutter **fastening** is excessive worn below the head (Fig. 25).



- 4 - the **self-braking** section of the screw is missing altogether or worn excessively (we recommend replacing the screw after it has been removed 5 times), see Fig. 26.
- 5 - the **fixing screw** is worn at the part which holds the cutter. If the diameter is 3 mm less than the original diameter (Fig. 27).
- 6 - the **tightening nut** is worn: if the height of the nut is half the original (Fig. 28).
- 7 - the **tightening nut** is inefficient because the washer has flattened (Fig. 29).



⚠ CAUTION! Use only genuine Fort spares to replace worn or broken parts.

9.3. General maintenance



Before cleaning, adjusting, servicing or repairing the machine, observe all the safety notices given in this Operator and Maintenance manual.



Before any work on the machine, switch the tractor engine off, remove the key from the ignition and apply the brakes.



Depressurized the hydraulic system.

Check to be certain the rotary mover is in a stabilized position.



Never work on the machine when it is moving.

After the first **8 hours of work**, the machine should be checked over paying special attention to:

- the correct tightening of all fixing devices;
- tensioning on all belt;
- leaks in any hydraulic plant component;
- correct lubrication of all transmission components.

Carry out the following checks **on a regular basis** and especially, at the beginning of **each working season**:

- Check and/or change the oil; lubricate/grease all points that require this as per the instructions;
- check cutter wear and conditions of their fastenings;
- check wear on guards and skirts;
- retension the belts;
- check tightening on all screws and bolts.

Before starting field work, check to make sure the mower is running correctly and without vibration.

9.4. Lubrication

Change the oil in the disk carrier bar and the overdrive gear box **after the first 50 work hours**. After this first oil change, change the oil after every 100 work hours or at least once a year.

Check oil level frequently.



1) Overdrive gear box (See Fig. 30)

T = Filler and emptying plug with dip stick

S = Bar vent plug

Use: **Variax EP 80 W 90 oil- 0.7 lt**

Empty the oil with the bar vertical.



2) Disk carrier bar (See Fig. 31)

C = Filler cap

U = Emptying plug

Use: **Variax EP 80 W 90 oil**

4-disk bar = 1.8 lt

5-disk bar = 2.3 lt

6-disk bar = 2.8 lt

7-disk bar = 3.3 lt

Fill with the bar vertical and also when you check the oil level.


- 3) The **joints, supports hinges, grease nipples** should be lubricated/greased after 20 work hours at least (See Fig. 32). Same holds good for the safety tripping device.
- 4) The **universal coupling** should be greased periodically as indicated in Fig. 32.

9.5. Off-season storage

At the end of the season, the machine should be stored with the **cutter bar horizontal** and all dirt removed.

Lubricate and grease all the points listed in the operator and maintenance manual. Give areas subject to abrasion a coat of **rust inhibitor** paint.

Slacken off the **"V" belts** and check to make sure the **canvans skirts** are not folded under.



I Leggere attentamente il Manuale di uso e Manutenzione prima di procedere a qualsiasi operazione sulla macchina (avviamento, uso, registrazione, manutenzione, ecc.)



AVVERTENZA:

questo segnale stà ad indicare un pericolo e verrà utilizzato ogni qualvolta potrebbe derivare un danno alle persone e/o alla macchina!

GB Become thoroughly familiar with the use and maintenance Instructions before proceeding with any operation on the machine (starting, use, adjustment, servicing, etc.).



WARNING:

this signal indicates a hazard and will be used each time either persons and/or the machine could be harmed!

F Lisez attentivement la notice d'utilisation et d'entretien avant d'effectuer une operation quelconque sur la machine (mise en marche, utilisation, reglæe, entretien, etc.).



ATTENTION:

ce symbole indique une situation de danger; il sera utilisè chaque fois qu'il y a des risques pour les personnes ou pour la machine!

ES Leer atentamente el manual de uso y mantenimiento antes de realizar operaciones con la maquina (arranque, uso, regulacion, mantenimiento, etc.).



ADVERTENCIA:


este mensaje indica un peligro y serà usado cada vez que pueda implicar un dano para las personas y/o para la maquina!

D Lesen Sie diese Betriebs- und Wartungsanleitung grundlich durch, bevor Sie irgendeine Arbeit (Starten, Benutzung, Einstellung, Wartung etc.) an der Machine vornehmen.



HINWEIS:

Dieses Signal zeigt eine Gefahr an und erscheint daher an all den Stellen, an denen ein Personen- und/oder Sachschaden moglich ist!



GRUPPO TIMONE
UNIT DRAW BAR

GRUPPO TIMONE
UNIT DRAW BAR


TAV. 1

POS.	CODICE	Q.TÀ				DESCRIPTION	DENOMINAZIONE	Q.TÀ	DESCRIPTION	DENOMINAZIONE			
		25/4	25/5	25/6	25/7								
44	851257	1	1	1	1	ROSETTA Ø 25,5x40x2	WASHER Ø 25,5x40x2	1	1	1	1	ROSETTA Ø 25,5x40x2	WASHER Ø 25,5x40x2
45	852201	1	1	1	1	SPINA A MOLLA TIPO R Ø 4x82	PIN R Ø 4x82	1	1	1	1	SPINA A MOLLA TIPO R Ø 4x82	PIN R Ø 4x82
46	009503	1	1	1	1	PERNO ATTACCO TERZO PUNTO	PIVOT	1	1	1	1	PERNO ATTACCO TERZO PUNTO	PIVOT
47	009510	1	1	1	1	SPINA DI ANCORAGGIO	PIN	1	1	1	1	SPINA DI ANCORAGGIO	PIN
48	852114	1	1	1	1	SPINA ELASTICA 5x15 UNI 6873	PIN 5x15 UNI 6873	1	1	1	1	SPINA ELASTICA 5x15 UNI 6873	PIN 5x15 UNI 6873
49	852203	1	1	1	1	SPINA A MOLLA TIPO R Ø 3x62	PIN R Ø 3x62	1	1	1	1	SPINA A MOLLA TIPO R Ø 3x62	PIN R Ø 3x62
50	850805	1	1	1	1	VITE T.E. M16x45 UNI 5739 8.8 ZINC.	BOLT M16x45 UNI 5739 8.8	1	1	1	1	VITE T.E. M16x45 UNI 5739 8.8 ZINC.	BOLT M16x45 UNI 5739 8.8
51	853181	1	1	1	1	RUBINETTO PER ALTE PRESS. 1/2 GAS	COCK	1	1	1	1	RUBINETTO PER ALTE PRESS. 1/2 GAS	COCK
52	009621	1	1	1	1	CHIAVISETTELLO REGOLAZIONE PIEDI	PIN	1	1	1	1	CHIAVISETTELLO REGOLAZIONE PIEDI	PIN
53	009622	1	1	1	1	PIEDE DI APPOGGIO	SUPPORT	1	1	1	1	PIEDE DI APPOGGIO	SUPPORT
54	855015	2	2	2	2	BOCCOLA AUTOLUB. 45x55x45	BUSHING 45x55x45	2	2	2	2	BOCCOLA AUTOLUB. 45x55x45	BUSHING 45x55x45
55	009594	1	1	1	1	COMPLESSIVO FORCELLA PORTA INAV.	FORK	1	1	1	1	COMPLESSIVO FORCELLA PORTA INAV.	FORK
56	851265	4	4	4	4	ROSETTA Ø 45,5x70x1 C72	WASHER Ø 45,5x70x1 C72	4	4	4	4	ROSETTA Ø 45,5x70x1 C72	WASHER Ø 45,5x70x1 C72
57	009607	1	1	1	1	SPINOTTO TRASVERSA	PIVOT	1	1	1	1	SPINOTTO TRASVERSA	PIVOT
58	852136	2	2	2	2	SPINA ELAST. 8x60 TIPO K	PIN	2	2	2	2	SPINA ELAST. 8x60 TIPO K	PIN
59	852207	1	1	1	1	SPINA A SCATTO	PIN	1	1	1	1	SPINA A SCATTO	PIN
60	009615	1	1	1	1	DISTANZIALE Ø 28,5x4,5x31	SPACER	1	1	1	1	DISTANZIALE Ø 28,5x4,5x31	SPACER
61	853100	1	1	1	1	INGRASSATORE M8 DIRITTO	GREASE NIPPLE M8	1	1	1	1	INGRASSATORE M8 DIRITTO	GREASE NIPPLE M8
62	009380	1	1	1	1	ALBERO MOTO	SHAFT	1	1	1	1	ALBERO MOTO	SHAFT
62	010156	1	1	1	1	ALBERO MOTO	SHAFT	1	1	1	1	ALBERO MOTO	SHAFT
63	855212	1	1	1	1	CUSCINETTO 35x62x14 6007 2RS	BEARING 35x62x14 6007 2RS	1	1	1	1	CUSCINETTO 35x62x14 6007 2RS	BEARING 35x62x14 6007 2RS
64	851260	2	2	2	2	ROSETTA Ø 35,5x45x0,5 C72	WASHER Ø 35,5x45x0,5 C72	2	2	2	2	ROSETTA Ø 35,5x45x0,5 C72	WASHER Ø 35,5x45x0,5 C72
65	851261	2	2	2	2	ROSETTA Ø 35,5x45x1 C72	WASHER Ø 35,5x45x1 C72	2	2	2	2	ROSETTA Ø 35,5x45x1 C72	WASHER Ø 35,5x45x1 C72
66	852053	1	1	1	1	ANELLO SEEGER E35 UNI 7435	RING E35 UNI 7435	1	1	1	1	ANELLO SEEGER E35 UNI 7435	RING E35 UNI 7435
67	009388	1	1	1	1	CONTROCUFFIA	CARDAN. JOINT PROTECTION	1	1	1	1	CONTROCUFFIA	CARDAN. JOINT PROTECTION
68	851222	2	2	2	2	ROSETTA Ø 8 UNI 6592 ZINC.	WASHER Ø 8 UNI 6592	2	2	2	2	ROSETTA Ø 8 UNI 6592 ZINC.	WASHER Ø 8 UNI 6592
69	001595	2	2	2	2	BUSSOLA PER SECONDA CATEG.	BUSH	2	2	2	2	BUSSOLA PER SECONDA CATEG.	BUSH
70	009617	1	1	1	1	PIATTO ATTACCO TRAVERSA	CONNECTIONG	1	1	1	1	PIATTO ATTACCO TRAVERSA	CONNECTIONG
71	010217	1	1	1	1	COMPLESSIVO TRAVERSA	BAR	1	1	1	1	COMPLESSIVO TRAVERSA	BAR
72	009592	1	1	1	1	COMPLESSIVO DISMINESTO	RELEASING	1	1	1	1	COMPLESSIVO DISMINESTO	RELEASING
73	855012	2	2	2	2	BOCCOLA AUTOLUB. Ø 40x50x40	BUSH	2	2	2	2	BOCCOLA AUTOLUB. Ø 40x50x40	BUSH
74	009620	3	3	3	3	COLUMNETTA VISSAGGIO CARTEF	STUD	3	3	3	3	COLUMNETTA VISSAGGIO CARTEF	STUD
75	009604	1	1	1	1	PERNO FERMA GANCIO	PIVOT	1	1	1	1	PERNO FERMA GANCIO	PIVOT
76	009618	1	1	1	1	PIATTO SGANCIO	PIVOT	1	1	1	1	PIATTO SGANCIO	PIVOT
77	009605	1	1	1	1	PERNO PORTA MOLLE A TAZZA	PIVOT	1	1	1	1	PERNO PORTA MOLLE A TAZZA	PIVOT
78	852419	36	36	36	36	MOLLA A TAZZA 16,3x34x2	SPRING	36	36	36	36	MOLLA A TAZZA 16,3x34x2	SPRING
79	009616	1	1	1	1	DISTANZIALE 17x40x15	SPACER 17x40x15	1	1	1	1	DISTANZIALE 17x40x15	SPACER 17x40x15
80	009606	1	1	1	1	PERNO PER DISMINESTO	PIVOT	1	1	1	1	PERNO PER DISMINESTO	PIVOT
81	852331	2	2	2	2	COPIGLIA Ø 4x35 UNI 1336	COTTER Ø 4x35 UNI 1336	2	2	2	2	COPIGLIA Ø 4x35 UNI 1336	COTTER Ø 4x35 UNI 1336
82	850879	2	2	2	2	VITE T.E. M16x50 UNI 5739 8.8 ZINC.	BOLT M16x50 UNI 5739 8.8	2	2	2	2	VITE T.E. M16x50 UNI 5739 8.8 ZINC.	BOLT M16x50 UNI 5739 8.8
83	850905	2	2	2	2	ROSETTA GROMMET A 16 UNI 1751 ZINC.	WASHER GROMMET A 16 UNI	2	2	2	2	ROSETTA GROMMET A 16 UNI 1751 ZINC.	WASHER GROMMET A 16 UNI
84	010218	1	1	1	1	PIASTRA ATTACCO RIDUTTORE	PLATE	1	1	1	1	PIASTRA ATTACCO RIDUTTORE	PLATE
85	009484	2	2	2	2	BOCCOLA IN NYLON	BUSH	2	2	2	2	BOCCOLA IN NYLON	BUSH
86	850017	2	2	2	2	VITE M8x16 UNI 6789 8.8 T.E. ZINC.	BOLT M8x16 UNI 6789 8.8 T.E	2	2	2	2	VITE M8x16 UNI 6789 8.8 T.E	BOLT M8x16 UNI 6789 8.8 T.E

GRUPPO TIMONE
UNIT DRAW BAR

TAV. 1

POS.	CODICE	Q.TA			DENOMINAZIONE	DESCRIPTION	DENOMINAZIONE	DESCRIPTION
		25/4	25/5	25/6	25/7			
87	850902	2	2	2	2	ROSETTA GROWER A 10 UNI 1751	WASHER GROWER A 10 UNI 1751	
88	009597	1	1	1	1	PULEGGIA A 4 GOLE DP 175	PULLEY	
89	009598	1	1	1	1	PULEGGIA A 4 GOLE DP 385	PULLEY	
90	010147	1	1	1	1	CATENA BLOCCA SOLLEVAMENTO	CHAIN	
91	853100	1	1	1	1	INGRASSATORE M8 DIRITTO	GREASE NIPPLE M8	
93	851528	1	1	1	1	TAPPO SFIATO TCNS 3/8	PLUG	
94	852240	-	-	-	-	GRILLO CON PERNO	TERMINAL	
95	005920	-	-	-	-	TENDITTORE M20x2,5	STETCHER	
97	851306	6	6	6	6	DADO AD ALETTE M10 UNI 5448	NUT	
100	010219	1	1	1	1	PERNO ATTACCO TRATTORE	PIVOT	
101	852155	2	2	2	2	SPINA ELASTICA Ø 12x30	PIN	
102	012947	1	1	1	1	PERNO ATTACCO TRATTORE	PIVOT	
103	003341	2	2	2	2	RONDELLA Ø 17 Ø n 45 SP. 4	WASHER Ø 17 Ø n 45 SP. 4	
104	011365	1	1	1	1	SET GUARNIZIONI	KIT GASKETS	
108	852247	-	-	-	-	MAGLIA RAPIDA PER CATENE	CHAIN QUICK LINKS	
109	851102	2	2	2	2	DADO AUTOBLOCCANTE M8 ZINC.	SELF LOCKING NUT M8	
110	851222	2	2	2	2	ROSETTA Ø 8 UNI 6592 ZINC.	WASHER Ø 8 UNI 6592	
111	850932	2	2	2	2	VITE TE 88 M8x20 UNI 5739 ZINC.	SCREW TE 88 M8x20 UNI 5739	



GRUPPO BARRA
UNIT BAR



TAV 2

GRUPPO BARRA
UNIT BAR

TAV. 2


POS.	CODICE	25/4	25/5	25/6	Q.TÀ	DENOMINAZIONE	DESCRIPTION
01	009446	4	5	6	97	VITE CON COLLARE ZIGRINATO M10x50	BOLT M10x50
02	009444	28	34	34	36	VITE CON COLLARE ZIGRINATO M10x28	BOLT M10x28
03	009445	12	15	24	31	VITE CON COLLARE ZIGRINATO M10x38	BOLT M10x38
04	009490	1	1	1	1	ASTA FORMA ANDANA	ROD
05	851117	2	2	2	2	DADO ESAG. M8 AUTOBLOC. BASSO	NUT M8
06	850912	2	2	2	2	ROSETTA Ø 8 UNI 6592 ZINC.	WASHER Ø 8 UNI 6592
07	850601	1	1	1	1	VITE TOST M8x35 UNI 5731 ZIN. 4.8	BOLT T10ST M8x35 UNI 5731 4.6
08	850600	1	1	1	1	VITE TOST M8x25 UNI 5731 ZIN. 4.8	BOLT M8x25 UNI 5731 4.6
09	009491	1	1	1	1	COMPL. BANDELLA ESTERNA	STRAP
10	851118	1	1	1	1	DADO ESAG. M10 AUTOBLOC. BASSO	NUT M10
11	850913	4	4	4	4	ROSETTA Ø 10 UNI 6592 ZINC.	WASHER Ø 10 UNI 6592
12	851248	1	1	1	1	ROSETTA Ø 11x40x3 ZINC.	WASHER Ø 11x40x3
13	009492	1	1	1	1	ANILLA RICHIAMO BANDELLA	SPRING
14	850824	1	1	1	1	VITE T.E. M10x80 UNI 5737 8.8 INC.	BOLT M10x80 UNI 5737 8.8
15	009460	1	1	1	1	COMPL. SUPPORTO BANDELLA	STRAP
16	009538	1	1	1	1	COMPL. SUPPORTO BANDELLA	STRAP
17	009493	1	1	1	1	COMPL. COPERCHIO BARRA 4 D'CHI	COVER
18	009466	1	1	1	1	COMPL. COPERCHIO BARRA 5 D'CHI	COVER
19	009494	1	1	1	1	COMPL. COPERCHIO BARRA 6 D'CHI	COVER
20	009505	1	1	1	1	COMPL. COPERCHIO BARRA 7 D'CHI	COVER
21	009495	1	1	1	1	COMPL. BASE INF. BARRA 4 D'CHI	BAR
22	009465	1	1	1	1	COMPL. BASE INF. BARRA 5 D'CHI	BAR
23	009496	1	1	1	1	COMPL. BASE INF. BARRA 6 D'CHI	BAR
24	009506	1	1	1	1	COMPL. BASE INF. BARRA 7 D'CHI	BAR
25	009415	1	1	1	1	INFORZO ANTER. BARRA 4 D'CHI	BAR
26	010206	1	1	1	1	INFORZO ANTER. BARRA 5 D'CHI	BAR
27	009417	1	1	1	1	INFORZO ANTER. BARRA 6 D'CHI	BAR
28	009418	1	1	1	1	INFORZO ANTER. BARRA 7 D'CHI	BAR
29	009458	1	1	1	1	COPERCHIO PER CONVOGLIATO E	COVER
30	851270	4	4	4	8	ROSETTA SCHNOR Ø 8	WASHER Ø 8
31	850018	4	4	4	8	VITE M8x20 UNI 5739 8.8 T.E.	BOLT M8x20 UNI 5739 8.8 T.E.
32	009453	8	11	12	15	VITE DEI SPECIALE	BOLT
33	009465	8	11	12	15	RICOLA IN NYLON	BUSH
34	009501	1	1	1	1	ESTANZIALE 12x21x5	SPACER
35	009497	2	3	1	1	ESTANZIALE 12x21x9	SPACER
36	009448	1	1	1	1	ESTANZIALE 12x21x12	SPACER
37	009450	2	2	2	2	DISTANZIALE 12x21x17	SPACER
38	009449	1	2	2	2	DISTANZIALE 12x21x15	SPACER
39	009459	4	5	6	7	COMPL. PATTINO	SKATE
40	851330	59	73	87	101	DADO ESAG. FLANGIATO M10 H=	NUT M10 H=
41	010203	3	4	5	5	DISCO PORTA COLTELLI	ROTOR
42	850924	3	3	3	3	DADO ESAG. M10 UNI 5587 ZINC	NUT M10 UNI 5587
43	852415	8	10	12	14	MOLLA A TAZZA 10,2x23x1	SPRING 10,2x23x1
44	009432	4	4	6	6	COLTELLO ROTAZIONE ANTIORAMA	CUTTER

POS.	CODICE	Q.TÀ			DENOMINAZIONE	DESCRIPTION
		25/4	25/5	25/6	25/7	
45	009431	4	6	8		COLTELLO ROTAZIONE ORARIA CUTTER
46	009433	8	10	12	14	PERNO PORTA COLTELLO PIVOT
47	85272	4	5	6	7	CUSCINETTO 30x72x18 6306 2RS C3 BEARING 30x72x18 6306 2RS C3
48	01204	4	5	6	7	SUPPORTO DISCO SUPPORT
49	85272	4	5	6	7	ANELLO DI TENITA 40x55x7 SEAL 40x55x7
50	009456	4	5	6	7	DISTANZIALE Ø 30x40x10 SPACER Ø 30x40x10
51	85612	4	5	6	7	ANELLO Ø 21x1 (29,87x1,78) SEAL Ø 21x1 (29,87x1,78)
52	85252	4	5	6	7	CUSCINETTO 30x72x19 6306 1Z C3 BEARING 30x72x19 6306 1Z C3
53	009478	1	1	1	1	TAPPO 3/8 GAS 3/16 DIN 908 PLUG
54	85288	2	2	2	2	ROSETTA 3/8" IN RAME WASHER
55	009411	1	1	1	1	RINFORZO POSTERIORE BARRA 4 REINFORCEMENT
56	009412	1	1	1	1	RINFORZO POSTERIORE BARRA 5 REINFORCEMENT
57	009413	1	1	1	1	RINFORZO POSTERIORE BARRA 6 REINFORCEMENT
58	009414	1	1	1	1	RINFORZO POSTERIORE BARRA 7 REINFORCEMENT
59	01206	1	1	1	2	COMPL. DISCO CONVOGLIATORE CONVEY
60	85420	4	5	6	7	MOLLA A TAZZA 18,3x35,5x2 SPRING 18,3x35,5x2
61	85452	4	5	6	7	DADO ESAG. M16x1,5 AUTOBLOC. NUT M16x1,5
62	85055	1	1	1	1	ANELLO SEEGER 40 E UNI 7436 SEAL SEEGER 40 E UNI 7436
63	85001	1	1	1	1	ANELLO SEEGER 80 I UNI 7437 SEAL SEEGER 80 I UNI 7437
64	85218	1	1	1	1	CUSCINETTO 40x80x18 6208 C3 BEARING 40x80x18 6208 C3
65	85514	1	1	1	1	ANELLO Ø 199 117,5x5,34 SEAL Ø 199 (117,5x5,34)
66	00467	1	1	1	1	SUPPORTO PORTA CUSCINETTO SUPPORT
67	00497	1	1	1	1	CONVOGLIATORE INTERNO CONVEY
68	00498	1	1	1	1	COMPL. SLITTA MOLTIPLICATORE SLIDE
69	00499	1	1	1	1	PIATTO ATTACCO CONVOGLIATORE PLATE
70	00500	1	1	1	1	ALETTA ATTACCO CONVOGLIATORE SUPPORT
71	85445	2	2	2	2	VITE T.E. M12x5 UNI 5737 8.8 BOLT T.E. M12x5 UNI 5737 8.8
72	85272	4	4	4	4	ROSETTA SCHNOR Ø 12 WASHER SCHNOR Ø 12
73	85502	3	3	3	3	VITE TOST M10x20 UNI 5731 ZINC. 4.6 BOLT T10ST M10x20 UNI 5731 4.6
74	85036	1	1	1	1	VITE T.E. M12x5 UNI 5739 8.8 BOLT T.E. M12x5 UNI 5739 8.8
75	85035	1	1	1	1	VITE T.E. M12x3 UNI 5739 8.8 BOLT T.E. M12x3 UNI 5739 8.8
76	85024	8	10	12	14	DADO ES. M10 UNI 5587 8.8 NUT M10 UNI 5587 8.8
77	00536	1	1	1	2	COPERCHIO CONVOGLIATORE CON PUNTE COVER
78	85504	1	1	1	1	SIGILLANTE SEALING
79	01016	1	1	1	1	TAPPO MAGNETICO PLUG
80	85014	4	4	4	4	RONDELLA PIANCA Ø 12 UNI 6592 ZN. WASHER
81	85044	1	1	1	1	VITE T.E. 8.8 M12x45 UNI 5737 BOLT T.E. 8.8 M12x45 UNI 5737



GRUPPO TRASMISSIONE
UNIT TRANSMISSION

TAV. 3



GRUPPO PROTEZIONI
UNIT PROTECTION

TAV. 4

GRUPPO PROTEZIONI
UNIT PROTECTION

TAV. 4

POS. CODICE	Q.TÀ		DENOMINAZIONE	DESCRIPTION	POS. CODICE	Q.TÀ		DENOMINAZIONE	DESCRIPTION
	25/4	25/5 25/6 25/7				25/4	25/5 25/6 25/7		
01 008425	1	-	TELO DI PROTEZIONE BARRA 4 DISCHI	SHIELD					
02 008426	-	1	TELO DI PROTEZIONE BARRA 5 DISCHI	SHIELD					
03 008427	-	-	TELO DI PROTEZIONE BARRA 6 DISCHI	SHIELD					
04 008537	-	-	TELO DI PROTEZIONE BARRA 7 DISCHI	SHIELD					
05 009401	1	-	COMPL. PROTEZIONE POST. 4 DISCHI	CHASSIS					
06 009384	-	1	COMPL. PROTEZIONE POST. 5 DISCHI	CHASSIS					
07 008407	-	-	COMPL. PROTEZIONE POST. 6 DISCHI	CHASSIS					
08 009523	-	-	COMPL. PROTEZIONE POST. 7 DISCHI	CHASSIS					
09 009404	1	-	TELAIO PORTA PROTEZIONI 4 DISCHI	CHASSIS					
10 009389	-	1	TELAIO PORTA PROTEZIONI 5 DISCHI	CHASSIS					
11 009405	-	-	TELAIO PORTA PROTEZIONI 6 DISCHI	CHASSIS					
12 009524	-	-	TELAIO PORTA PROTEZIONI 7 DISCHI	CHASSIS					
13 008402	1	-	COMPL. PROTEZIONE ANTER. 4 DISCHI	CHASSIS					
14 008385	-	1	COMPL. PROTEZIONE ANTER. 5 DISCHI	CHASSIS					
15 009406	-	-	COMPL. PROTEZIONE ANTER. 6 DISCHI	CHASSIS					
16 009522	-	-	COMPL. PROTEZIONE ANTER. 7 DISCHI	CHASSIS					
18 010229	1	1	STIPA DI GUIDA TELO DI PROTEZIONE	BRACKET					
20 008395	1	1	BIELLA COMANDO SOLLEVAMENTO	ROD					
22 009534	-	-	LAMIERA ESTERNA CONVOGLIATA	PLATE					
23 009478	2	2	PERNO PER SOLLEVAMENTO BARRA	PIVOT					
24 009477	2	2	FASCETTA PER FISSAGGIO TELO	GAUGE					
25 830996	4	7	VITE T.E. M10x50 UNI 5737 8.8 ZINC.	BOLT M10x50 UNI 5737 8.8 T.E.					
26 850943	4	4	VITE T.E. M12x30 UNI 5739 8.8 ZINC.	BOLT M12x30 UNI 5739 8.8 T.E.					
27 850946	-	-	VITE T.E. M14x50 UNI 5739 8.8	BOLT M14x50 UNI 5739 8.8 T.E.					
30 851118	6	9	DADO ESAG. M10 AUTOBLOCC. BASSO	NUT M10					
32 850903	4	4	ROSETTA CROVIERA 12 UNI 1751 ZINC.	WASHER GROWER A 12 UNI 1751					
33 852331	2	2	COPIGLIA Ø 4x35 UNI 1336 ZINC.	COTTER Ø 4x35 UNI 1336					
35 851502	-	-	VITE TOST M10x20 UNI 5737 ZN. 4.6	BOLT TOST M10x20 UNI 5737 ZN. 4.6					
36 850823	2	2	VITE T.E. 8.8 M10x70 UNI 5737 ZN.	BOLT T.E. 8.8 M10x70 UNI 5737 ZN.					
37 850945	-	-	VITE T.E. 8.8 M12x40 UNI 5737 ZN.	BOLT T.E. 8.8 M12x40 UNI 5737 ZN.					
38 850914	-	-	RONDELLA PIANA Ø 12 UNI 6692 ZN.	WASHER					
39 851104	-	-	DADO AUTOBLOCC. M12	NUT M12					